


VSS35 Connection Diagram




1. The optional camera you bought from Embest is an analog camera. You can connect the camera directly to VSS35 through the yellow Video connector.
2. The camera has provided with a 12V power supply adapter.



3. Power on VSS35 and connect to PC through Ethernet (Router).




4. Set your PC IP address as shown on below diagram:



5. Login VSS35 system from 192.168.0.123.

User: admin; Password: 123456



6. You will get into VSS35 interface.

